

SPACE STEP


www.blum.com

 **blum**[®]

SPACE STEP



Standardanwendungen | Standard applications | Applications standard | Applicazioni standard | Aplicaciones estándar |
Rozwiązania standardowe | Стандартные конструкции



Sonderanwendungen | Special applications | Applications spéciales | Applicazioni speciali | Aplicaciones especiales |
Rozwiązania specjalne | Специальные конструкции



<http://www.blum.com/2LoLDHQA>



Planung | Planning | Planificación |
Progettazione | Planificación |
Planowanie | Проектирование



Einstellung | Adjustment | Réglage |
Regolazione | Ajuste | Regulacja |
Регулировка












Montage | Assembly | Montage |
Montaggio | Montaje | Montaż |
Монтаж







Demontage | Removal | Démontage |
Smontaggio | Desmontaje |
Demontaž | Демонтаж

SPACE STEP




SPACE STEP



i


NL ≤ 450	NL 410
NL > 450	NL 460




SPACE STEP




i




1



i




i




2

(3.5 x 15) *(3.5 x 10)



3

(3.5 x 15)







SERVO-DRIVE
by Blum


TIP-ON
by Blum

TIP-ON
BLUMOTION
by Blum


SPACE STEP




4  (4 x 15)




5




6  (4 x 15)




7


 (3.5 x 25)




8



9







SPACE STEP




4 (4 x 15)




5




6 (4 x 15)




7 (3.5 x 25)





8






9








SPACE STEP




10  (3.5 x 25)






12  (3.5 x 15)





SPACE STEP

 blum®



SPACE STEP



SPACE STEP



Julius Blum GmbH
Beschlägefabrik
6973 Höchst, Austria
Tel.: +43 5578 705-0
Fax: +43 5578 705-44
E-Mail: info@blum.com
www.blum.com

